

Bain Marie VRB / VRB-DI / VRB-SB

Installation and operating instructions OI-204501-1

1. Place the Bain Marie on a level surface, and adjust the level.
2. Remove all protective plastic from all surfaces, inside and outside.
3. Insert the plug into an easily accessible socket, which is easily accessible after assembly.

Please check technical documentation about power type.

4. Fill in with hot water to approx. 5 cm. above bottom level (depending on the depth of the canteens) Minimum level is 1 cm above the thermostat sensor pocket, inside tub.
5. The thermostat is also an on/off switch, the green lamp light up constantly when the Bain Marie is on.
6. Set the thermostat in wanted temperature.
7. The Bain Marie has to be heated to right temperature before use, and food must at least have serving temperature by filling.
8. After use, set the temperature in off position. And drain valve can be opened for discharging water.
9. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
10. We recommend top heat from Stayhot.
11. **Cleaning:** The Bain Marie must be cleaned daily after use with mild soap and water. Do not use soap with acids, iodine or fluorine! Rinse well with water and a suitable cloth.

OBS! Never use high-pressure water or water hose to clean the Bain Marie!

Service:

Turn the main switch (thermostat) in off-position and pull out main cord. Remove 2 pcs. screws in front/under the heating unit, now you can remove the whole unit out from the Bain Marie. Thermostat, lamp, thermometer and elements are now available. Be careful with the insulant, and put it right back in place before you reverse the heating unit back in place. OBS! Only qualified personnel or service agents are allowed for this operation!

Replacement of main cord has to be done by qualified personel.

